

# ROBUS **R** LEATHER

*Real leather floor tiles, without the cost.*

Robus Leather Floor Tiles are crafted from commercially available leather scrap. This very durable and versatile leather is manufactured through an intricate milling process that produces the beautiful character of these leather floor tiles.

Robus Leather offers a variety of colors and finishes to design one-of-a-kind interiors that command attention. These stunning leather floor tiles create luxurious surroundings that are practical, long lasting, and easy to maintain. You can have Robus Leather Floor Tiles in virtually any room in your home or workplace. The affordability and durability of this floor system will delight you for years.

## Mega Gator Finishes



## Spanish Crush Finishes



Disclaimer: Leather colors shown have been reproduced within the limitations of the printing process. Color samples shown can vary slightly from the actual leathers.

# Robus Bonded Leather Floor Tiles

## Installation Instruction Steps:

1. Remove leather tiles from packing and allow to acclimate for at **least** 72-hours. Do not install tiles at temperatures below 50 °F or above 90 °F.
2. Be certain that substrate is structurally sound, level, oil-free, clean and free of dust. All holes and crevices must be filled. Leather tiles may be installed on unpainted dry wood or fully cured concrete surfaces.
3. Install from center working outward. Color within tiles may vary slightly. This is an inherent feature and adds to the character of this natural product.
4. Install tiles using Robus Leather Premium Adhesive. Use trowel size of 1/16 x 1/16 x 1/16 at a spread rate of 150 sq. ft. per gallon. Tiles should be placed on glue no sooner than 5-minutes and no later than 10-minutes after troweling.
5. Tiles should be rolled during and after installation using a 75-lb to 100-lb roller. Remove excess adhesive immediately using a damp cloth. Do not walk on floor tiles for 12-hours after installation. Do not place furniture or fixtures on installed floor tiles for 24-hours.
6. To seal seams and protect tiles, apply Robus Leather Protective Coating and Sealant 24-hours after installation. Two protective coats are recommended.

**Maintenance:** Use a damp (not wet) mop or soft cloth. Never use harsh detergent cleaners, liquid floor waxes, polishes or ammonia. Only use a soft brush attachment when vacuuming.

**Moisture:** Use the anhydrous calcium chloride ASTM Test Method 1869-98 to test for vapor emission, and also test for excess alkalinity. A pH higher than 9.0 requires corrective measures. Do not install tiles if moisture emissions are over three pounds of moisture per a 1000 sq. ft. area during a 24-hour period.

## Limited Warranty and Limitation on Damages

**Coverage:** Robus Bonded Leather Floor Tiles are warranted not to be defective in material or in workmanship for ten (10) years from the date of purchase.

**General Warranty Information:** The warranty does not cover damage caused by improper installation, improper sub-flooring, excessive humidity or use of a non-recommended adhesive. Mistreatment of any kind, including mechanical impact, scuffing caused by hard objects, water damage, plumbing leaks, fire damage, inadequate maintenance, or improper usage will void this Limited Warranty. Mistreatment or improper usage includes damage from moving furniture across the surface without adequate protection, rolling casters on furniture and appliances, rotating vacuum cleaners, and dropping heavy or sharp objects onto floor tiles. Further excluded are problems due to extreme temperatures, heat or cold, sunlight, scuffs, stains, discoloration, rips, tears, gouges or indentations. Normal wear and tear is expected. However, no warranty is extended unless all installation instructions are followed including the protective coating application. Failure to apply Robus Leather Coating and Sealant, and to use Robus Leather Premium Adhesive will void this Limited Warranty.

**Warranty Remedy:** Robus will furnish comparable leather tiles of similar color, pattern, and quality for either the repair of the defective area or the replacement of the defective tiles at Robus's option, and reimburse the cost of reasonable reinstallation labor if professionally installed originally.

**Consequential or Incidental Damages Excluded:** Robus will not pay for any loss, expense or damage other than for the tiles purchased, and labor cost of re-installation.

**Implied Warranties:** There are no implied warranties including warranties of **merchantability** and **fitness for a particular purpose or use** extending beyond the Limited Warranty noted above. No representative, employee or agent of Robus is authorized to modify or change the limited warranties or limitations on damages as stated herein.

**How to Make a Claim:** Promptly contact retailer in writing and include: name of product purchased, lot number, quantity, cost, date purchased, installer, and installation date. Review period is within (60) days after the claim is filed with Robus Leather Corporation, 1100 W. Hutchinson Lane, Madison, Indiana 47250 U.S.A., Telephone (812) 273-4183, FAX (812) 273-6671.

## Architectural Specifications Sheet

### CSI Master Specifications:

Product Name:	Robus Leather Recycled Floor Tiles
Material:	Recycled Leather, Natural Latex
Tile Size:	24" x 24"
Thickness:	3.2 mm (0.125")
Smoke Density:	ASTM E-662 Less than 200 (20m, flaming)
Flooring Radiant Panel:	ASTM E-648 Class II
Static Load Limit:	ASTM F-970 100 lbs PSI



1100 W. Hutchinson Lane  
Madison, Indiana 47250 U.S.A.  
Phone: 812-273-4183  
Fax: 812-273-6671  
www.robust.com

